

---

# STANDARDS MANUAL

---

Index	Page
INTRODUCTION	SM.2
GENERAL NOTES	
Tyre Size Designation	SM.3
Load Capacities	SM.3
Inflation Pressure - Tyre Inflation Pressure Maintenance	SM.4
Tyre Removal Criteria	SM.5
Tyre Measuring Procedure	SM.5
Tyre Dimensions	SM.5
Tyre Selection	SM.6
Heating of Tyres	SM.7
Use of Aircraft Tyres in Other than Aircraft Service	SM.7
E.T.R.T.O. STANDARDS	
Group 1 Tyres	SM.8, SM.9
Group 2 Tyres	SM.10 to SM.17
Group 3 Metric Tyres	SM.18, SM.19
Group 4 Radial Tyres	SM.20, SM.21



S  
M

**This sign shown in the margin indicates where a new line has been added during the last up-dating of the Standards Manual for Aircraft Tyres.**